

Stafsjö
SINCE 1666

Content

Original

Installation and service instruction

Knife gate valves

English →

Einbau- und Betriebsanleitung

Stoffschieber

Deutsch →

Instrucciones de instalación y servicio

Válvulas de guillotina

Español →

Instructions de montage et d'entretien

Vannes à guillotine

Français →

Istruzioni per l'installazione e l'uso

Di valvole a ghigliottina

Italiano →

Installatie- en onderhoudshandleiding

Meskantafsluiters

Nederlands →

Installasjons- og serviceinstruksjon

Skyvespjeldventiler, knivtype

Norsk →

Instruções de instalação e manutenção

Válvulas guilhotina

Português →

Instrucțiuni de instalare și service

Vane cu sertar cuțit

Română →

Original

Installations- och driftinstruktion

Skjutspjällsventiler

Svenska →

Original

Installation and service instruction

Knife gate valves

Stafsjö Valves AB

SE-618 95 Stavsjö, Sweden




+46 11 39 31 00 | sales@stafsjo.se | www.stafsjo.com

A) General

In this instruction a “knife gate valve” is shortly called “valve”.

A1 Symbols


In this instruction notes and warnings are marked with symbols:

 XXXXXX	Danger / Warning Points out a dangerous situation which may cause personal injuries or death.
	Advice Has to be respected.
	Information Information useful to follow.

If these notes and warnings are not respected by the user, dangerous situations may occur and may invalidate the warranty of the manufacturer.

A2 Valve destination

Valve types **D2G, HG, HL, HP, HX, JTV, MV, RKO, RKS, SLF, SLH, SLV, SLX, TV, WB** (WB, WB11, WB12, WB14, WB14E) and **XV** are destined – after installation between flange(s) in a pipe system – to shut off, to open or to control the flow within the admissible pressure/temperature limits, defined in data sheet on www.stafsjo.com.

The flow shall be without vibrations and/or pressure chocks. The surrounding environment should not imply any risk to the valve. This also implies to explosive environment – except for valves classified for ATEX- area  and marked accordingly. Knife gate valve types SLF, SLH, SLV, SLX, WB, WB11, WB12, WB14, WB14E and XV are intended for use in applications with liquid fluids, not together with a dry media.

Installation of the knife gate valve is preferred with the actuator in an upward position – except for RKO, RKS, JTV and D2G.

At valve operation respect:

- The manufacturers declaration to EC directives,
- This original installation and service instruction which is supplied together with the valve.

If the valves are placed in any type of media or application that the valve material configuration is not suitable for, Stafsjö cannot be held responsible for problems and incidents that may arise.

Stafsjö Valves AB does not accept any responsibility if this “Valve destination” is not observed.

A3 Related documents

Further information on the valves is available on www.stafsjo.com.

ds+valve type (i.e. *ds-MV*) = Data sheet with technical information (dimensions, material specification etc.)

mi+valve type (i.e. *mi-MV*) = Instructions for maintenance on each valve type.

sp+valve type (i.e. *sp-MV*) = Specify spare parts for each valve type.


acc+type of accessory (i.e. *acc-SV*) = Accessory for different types of valves. I.e solenoid valve.

A4 Valve marking

Each valve is labelled as follows:

Type	Identification	Remarks
Manufacturer	E.g. Stafsjö	See label and valve body.
Manufacturer address	E.g. Stafsjö Valves AB, SE-618 95 Stavsjö, Sweden, www.stafsjo.com	See type label.
Conformity	E.g. CE 2529 (if applicable)	Conformity with Pressure Equipment Directive 2014/68/EU and notified body. See type label.
ATEX conformity	E.g. II 2/2G Ex h IIC T6...T5 Gb/Gb II 2/2D Ex h IIIC T68 °C ...T100 °C -20°C ≤ Ta ≤ +60°C (if applicable)	Approved to be used in specified ATEX area. See type label.
Ser.No (Serial number)	E.g. 400-00634372-110-002	Sales order type - Sales order number - Order line - Sequence number. See type label.
Type	E.g. MV	Knife gate valve type. See type label.
Size	E.g. DN 300/12"	See type label. DN on valve body.
Rating	E.g. Max 10 bar working ps	Max working pressure at 20 °C. See type label and valve body.
Rating	E.g. Max 10 bar differential ps	Max differential pressure at 20 °C. See type label.
Drilling	E.g. PN10 – EN 1092-1	Flange drilling standard. See type label.
Body	E.g. EN 1.4408	Valve body material See type label and valve body.
Gate	E.g. EN 1.4404	Gate material. See type label.
Seat	E.g. EPDM	Valve seat material. See type label.
Year	E.g. 2022	Manufacturing year. See type label.

The type label should not be covered so that the installed valve remains identifiable.

	Refer to the "Serial number" of the valve marking at any contact with Stafsjö.
---	--


A5 Transport, storage and handling

Note

Additional requirements may be found in the actuator instruction, if any.

Storage and transport:

The valves are delivered with gate in, for the valve type, correct position during storage to ensure its function and to protect the polished surface of the gate. Store the valve in a clean and dry environment and protect it against dirt, dust and other contamination. Do not expose the valve to direct sunlight. If the valve is stored outside, it shall be wrapped tightly in a plastic foil or similar to protect it against moisture or any dirt contamination. It should also be stored high enough without any risk to be covered in snow or enclosed by water.

	The valve has been packed according to the terms of delivery. It is important to make a visual inspection at arrival. If transport damage is detected, report to the transportation company.
---	--

Handling:

Lifting and moving shall be carried out with soft straps. Place and fasten the soft strap on the valve body as shown in fig.1, ensure that the valve is properly balanced before lifting. Make shure that all equipment is designed to hold the weight of the valve.



Fig.1

	<p>Never place lifting equipment:</p> <ul style="list-style-type: none">• On the actuator, accessories or gate guards.• In the bore of the knife gate valve, since it causes damages to the seat and retainer ring.
--	--

	<p>Specifically note that threaded hole on top of pneumatic cylinder type, is only for handling the cylinder itself. See figure 2.</p>
--	--




Fig.2

B) Installation/functional check

	<p>This instruction includes safety recommendations for foreseeable risks at installation into a (pipe) system. The user is responsible to complete this instruction with warning notes for system-specific aspects. All requirements of the system shall be observed.</p>
--	--

B1 Safety warnings at installation

	<ul style="list-style-type: none">• Installation shall be performed by qualified personal. Qualified are those persons who, due to experience, can judge the risks and execute the work correctly and who are able to detect and eliminate possible risks.• After installation, the function of the valve shall be in accordance with the valve and the actuator (if any) destinations, see section A2.• At the end of the installation the gland bolting shall be tightened according to table in section B7.• A valve without an actuator must not be installed into the (pipe) system.• Some valve types can be installed as end valves. Contact Stafsjö for specific requirements and information.
	<ol style="list-style-type: none">1. A valve with an actuator shall only be operated if:<ul style="list-style-type: none">• The valve is installed between flanges or between a flange and a protective device.• The gate guards are installed on the beams on automatic operated valves.2. If the knife gate valve is installed as an end valve in a pipeline, always install protective equipment to prevent people getting to close to the valve and being exposed to the media transported in the system when the valve opens.3. Do not climb or stand on the valve and/ or actuator <p>People's life and health is at stake if this is not observed. Any other action is the responsibility of the user.</p>

B2 Conditions for installation

Make sure:


- To install valves according "Valve destination", see section A2. Observe valve marking, see section A4.
- That the pipe section is not exposed to vibrations or other mechanical stresses which could deform the valve body and affect the valve's tightness and/or ability to operate.
- That the valve environment does not imply any risk to the valve, the actuator or the accessories. This also implies to explosive environment – except for valves classified for ATEX- area and marked accordingly.
- That flanges, pipeline and the valve are empty, free from solid and sharp particles.

- That the valve is installed between flange(s) (fixed or loose) to ensure that the valve is securely fixed and that the flange keeps tight.
- That the knife gate valve is protected against radiant heat, if the valve is placed near a heat source whose temperature exceed maximum allowable temperature for the valve or its actuator.
- The mating (=gasket contact) surface of the flange cover the retainer ring completely. Detailed information on flange drilling, threads, length and number of bolts is available in data sheet on www.stafsjo.com.
- To follow those instructions which are supplied with an actuator (if any).
- The pipeline is free from pressure.
- Additional requirements may be found in the actuator instruction – specifically to adjust the correct OPEN and CLOSED positions before the valve is installed.

B3 Pressure, flow direction, valve position and flushing

When the knife gate valve is **open**, $P1=P2$, the pipe line pressure may not exceed maximum allowable working pressure body according to each valve. When the valve is **closed**, the differential pressure ΔP , is the difference between $P1$ and $P2$ ($\Delta P = \pm (P1-P2)$).

The differential pressure ΔP may not exceed maximum allowable differential pressure according to each valve. Maximum allowable differential pressure for closed valve is available in data sheets.



- Valve types **D2G, HG, HL, HP, HX, WB, WB11, WB12, WB14 and WB14E, SLF, SLH, SLV, SLX and XV** are bi-directional and can therefore be installed independent of the pressure ratio in any direction in the pipeline.
- **Valid for MV only:**
This valve type has different differential pressure ΔP capacities in the flow directions. The maximum ΔP capacity of the valve is achieved when the SEAT SIDE is installed as the valve outlet (towards $P2$) provided that $P1 > P2$. When the valve is closed, the pressure ratio shall be $P1 > P2$. Some sizes of MV equipped with specific seats are capable to handle certain differential pressure in reversed pressure direction. For further information, see data sheets on www.stafsjo.com.
- **Valid for JTV, RKO and RKS only:** These valve types have different differential pressure ΔP capacities in the flow direction. The maximum ΔP capacity of the valve is achieved when the seat side is installed as the valve inlet (towards $P1$) provided that $P1 > P2$. When the valve is closed, the pressure ratio shall be $P1 > P2$.
- **Valid for TV only:**
This valve shall be installed with the seat side to the tank. The removable retainer ring shall be mounted towards the tank which implies that changing of the seat can only be done when the tank is empty.
- All valve types, except for valves **D2G, JTV, RKO and RKS** are preferred to be installed in a horizontal pipe (system) with the actuator in a vertical upright position.
Valid for D2G, RKO, JTV and RKS only:
These valve types are designed to be installed in a vertical pipe.
- Valves installed in inclined position are mainly affected by type of media, flow rate and sedimentation in the process. To estimate the effect of such is the responsibility of the customer. Stafsjö will assist on request.
- A valve can be equipped with flushing to improve function depending on type. When so is the case, customer has too secure that flushing port will not be clogged. Preferably by use of check valve mounted directly on valve port. Stafsjö can assist on request.

B4 Necessary support for special cases

The dead weight of a valve in large dimension together with its actuator or a small valve with heavy actuator, may cause tensions/deformations in the valve that could affect the valve's function, specifically when it is installed at inclined positions or in a vertical pipe. In these cases, the valve and/or actuator shall be supported to avoid functional failure.

Valves that are exposed to vibrations or other mechanical stresses can be subject to forces that will affect valves tightness and ability to operate. In these cases, the valves and actuators shall be supported to avoid function failure. Support details are the responsibility of the customer. Stafsjö will assist on request.

B5 Steps to install

On handwheel operated valves, when the handwheel is not assembled at delivery, follow the steps below to assemble the handwheel to the valve.




Fig. 4 Assembling of handwheel

Handwheel with <u>non-rising stem</u>	Handwheel with <u>rising-stem</u>		
<p>1. Assemble the handwheel to the valve. Check that there is not any play between the actuator, bearing and yoke. If there is, eliminate the play by rotating the stem 360 degrees clockwise. Then fixate the handwheel with a locking nut.</p>	<p>1. Make sure that the safety pin is mounted in order to lock the gate. Loosen the nuts from the tie rods and remove the temporary yoke plate.</p>	<p>2. Assemble the handwheel unit to the tie rods and fixate it with washers and nuts. Attach the gate clevis to the gate and fixate with clevis pin and split pins.</p>	<p>3. Remove the safety pin. For safety reasons, the pin shall not be removed until the hand-wheel unit is assembled and the gate clevis is properly attached to the gate.</p>

When the handwheel is assembled, install the valve into the pipe (system).

When installing the valve, make sure that:

- The valve's centre line is on the same centre line as the flanged pipes.
- Flange surfaces of the pipe and valve must be exactly parallel.




Fig. 5

If the flanges and the valve are not centred, the valve may be damaged by erosion and a dirt pocket may occur which can lead to clogging and corrosion of the valve.

	<ul style="list-style-type: none"> • Valve type RKO and XV must be installed in <u>closed</u> position only. • Valve type SLV, SLF, SLH and SLX must be installed in <u>open</u> position only! • When the SLV and SLF valve body are closed by bottom cover and/or when SLH and SLX purge ports are closed by plugs, flushing is recommended through the purge ports at service if it is not clean fluid.
--	---



1. Place the gaskets between the valve body and the flange. Check that the gasket is well centered and covers the complete surface of the retainer ring.

	<p>Valve types WB (DN 350-DN 600), WB11, WB12, WB14, SLV, SLF, SLH and SLX only: These valve types are equipped with integrated rubber flange gaskets – additional gaskets are not necessary.</p>
--	--




2. Lubricate the bolts. This allows correct pre-setting of the flange and makes it easier to dismantle the bolting later.

	<p>All Valve types: Flange bolts of right length are necessary:</p> <ul style="list-style-type: none"> • Too long bolts could deform the valve body and result in leakage in the flange. • Too short bolts could deform the threaded holes in the valve body at installation. <p>Choose bolts with the correct thread and length according to the flange drilling information in the data sheet.</p>
--	---

3. Tighten the bolts first manually and then evenly and crosswise, for a uniform load of the gasket, with a torque as required by the gasket manufacturer. Valve type **SLV, SLF, SLH and SLX** shall be assembled with the mating surfaces of the valve body and the pipe flanges up to metal/metal contact. See fig. 6.

<p>!</p>	<p><i>Valid only for SLV, SLF DN 80-DN 450, SLH DN 80-DN 450 and SLX DN 80-DN 450</i></p> <p style="text-align: right;">Fig. 6</p>  <p>Make sure that the flange is centered and is covering the metal frame around the seat. Tighten flange bolts crosswise to eliminate any gap between body and flange.</p>
<p>!</p>	<p>To ensure the seats will stay in correct position after every valve manoeuvring, we recommend using load distribution rings (LDR) on the SLV, SLF, SLH and SLX valves when:</p> <ul style="list-style-type: none"> • The pipelines are rubber lined and/or the flanges are partly or entirely rubber covered. • The inner diameter of the connecting pipes and/or flanges is larger than the inlet diameter of the valve. • The outside diameter of the raised flange is not large enough to cover the metal frame around the seat in order to accomplish metal to metal contact between the valve and flange.  <p style="text-align: right;">Fig. 7</p> <p><i>If load distribution rings are ordered they are as standard assembled on the valve upon delivery.</i></p>



4. To finish the installation, make an operational test by opening /closing the valve. Observe the actuator (if any) instructions.
- A valve with handwheel should be operated with normal hand force. Exceptional force used to close the valve can damage it.
 - A valve with electric/pneumatic actuator shall be operated by the plant control signals into its end positions, i.e. OPENED and CLOSED.
 - At connection of an actuator to the plant control system the actuator instructions shall be followed.
5. If the pipeline is to be cleaned by flushing in order to wash out impurities, the valve must be opened 100 %.

	<i>Valves with actuator supplied by Stafsjö are exactly adjusted in the end positions: This adjustment shall not be changed as long as the valve operates correctly.</i>
	Only for valves with electric actuator: Ensure that the actuator motor stops <u>by the signal of the limit switch for closed and open position</u> of the actuator. Exceptional force may damage the valve. The signal of the <u>torque switch</u> may be used for signal for faulted conditions. <i>For further information, see the actuator instruction.</i>
	Only for valves with mechanical lockout: The mechanical lockout is designed to lock the gate in either open or close position. Note that the actuator must <u>also</u> be isolated from all energy sources, including electricity, air supply or hydraulic supply, to ensure it will not operate the valve while it is mechanically locked. Any attempts to operate the valve when it is mechanically locked may compromise the seal and damage the mechanical lockout and valve. Stafsjö recommends <u>avoiding</u> the use of mechanical lockout in combination with all spring-loaded and single-acting actuators. Contact Stafsjö for advice and further information.

B6 Installation in an ATEX-classified area

Note:

Additional requirements may be found in the actuator instruction, (if any). This ATEX instruction is valid along other instructions in this document.

	In ATEX-classified zones, in accordance with ATEX Directive 2014/34/EU, only valves with ATEX-classification and the relevant valve marking shall be installed.
	Additional requirements are to be found in Stafsjö's ATEX installation instructions for respective category




Additional to the requirements above make sure that:

- The valve is part of the plants earthed system.
- The user has performed a risk analysis of the pipeline and valve in accordance with the guidelines of ATEX Directive 2014/34/EU.

B7 Pressure testing after installation (if necessary)

Each Valve has been pressure tested before delivery by the manufacturer. For pressure test of the pipe section with a knife gate valve installed the conditions for the system apply but with the following restrictions:

- The pressure test **shall not exceed 1,5 x max. working pressure of the valve body** (see valve marking). The gate shall be open.
- Pressure test with valve in closed position shall not be tested more than **1,1x max. differential pressure in preferred pressure direction**, (see datasheets) in order to prevent overload of the gate.


	<i>Immediately at this operation check the stuffing box tightness. In case of leakage: Tighten the gland nuts evenly crosswise and bit by bit until leakage stop. Do not tighten more than necessary!</i>															
	<p>Recommended maximum torque</p> <table border="1"> <thead> <tr> <th>DN</th> <th>DN 50 – DN 80</th> <th>DN 100 – DN 150</th> <th>DN 200 – DN 300</th> <th>≥ DN 350</th> </tr> </thead> <tbody> <tr> <td>Nm</td> <td>20</td> <td>25</td> <td>30</td> <td>35</td> </tr> <tr> <td>lbf x ft</td> <td>15</td> <td>18</td> <td>22</td> <td>26</td> </tr> </tbody> </table>	DN	DN 50 – DN 80	DN 100 – DN 150	DN 200 – DN 300	≥ DN 350	Nm	20	25	30	35	lbf x ft	15	18	22	26
DN	DN 50 – DN 80	DN 100 – DN 150	DN 200 – DN 300	≥ DN 350												
Nm	20	25	30	35												
lbf x ft	15	18	22	26												
	For the valves HP, HX and other high-pressure versions, observe the additional instruction: "Installation of high-pressure knife gate valves – tighten the gland or double gland".															

B8 Disassembling the valve

Note:

Additional requirements may be found in the actuator (if any) instruction.

For the valve the same safety instructions apply as for the pipe (system) and for the control system to which the actuator (if any) is connected. The respect of these requirements shall be followed.

 Danger	Disassembling the valve from the pipeline may only be done when: <ul style="list-style-type: none">• the pipe section is free from pressure and is empty• all the electronic and/or pneumatic/hydraulic connections have been disconnected People's life and health is at stake if this is not observed. Any other action is the responsibility of the user.
--	--

Disassemble the valve in following steps:

1. Depressurise the pipe section and drain it completely.
2. Disconnect all electric and/or pneumatic/hydraulic connections.
3. Fasten and use soft straps if necessary (see also Fig.1 in section A5). Make sure not to damage the valve, gate, gate guards or any accessory.
4. Take out the valve from the pipe carefully in order to protect the flange gaskets.
5. At transport and storage observe section A5.


C) Service and maintenance

Note

Additional requirements may be found in the actuator instruction.



The user shall make a risk analysis as per Machinery Directive 2006/42/EC for the pipe system. Stafsjö supplies the following documents for it:

- The original installation and service instruction of the valve.
- An installation and service instruction of the actuator (if any)
- The Declaration of conformity) to EC Directives.

	This instruction includes safety notes for industrial application for any foreseeable risk at use of the valve. It is the responsibility of the user/planner to complete this instruction with warning notes for plantspecific risks.
---	---

Further information on Stafsjö's valves is available on www.stafsjo.com.

C1 Safety warnings at service and maintenance

	<ul style="list-style-type: none"> • At operation, the function of the valve shall be in compliance with the <Valve Destination>, see section A2. • The service conditions of the valve shall be in compliance with the valve markings, see section A4. • Service and maintenance shall be performed by qualified personal. Qualified are those persons who, due to experience, can judge the risk and execute the work correctly and who are able to detect and to eliminate possible risks. • At service the valve shall be inspected regularly for leakage or other effects that could affect the safety for the personnel. The interval for these inspections depends on operating data, see C3 • If a fault or problem is detected at an inspection or manoeuvre test, the knife gate valve must be maintained as soon as possible • Valves, destined for use in an ATEX classified zone, must be marked according to the ATEX directive. • At any start up, the stuffing box shall be visually inspected for leakage. If any leakage is detected, the nuts on the gland shall be retightened according to table in section B7. Except for this action, no maintenance is allowed on the valve when the pipeline is pressurised. • If the valve is supplied with mechanical lockout to lock the gate in either open or close position, note that the actuator must <u>also</u> be isolated from all energy sources, including electricity, air supply or hydraulic supply, to ensure it will not operate the valve while it is mechanically locked. Any attempts to operate the valve when it is mechanically locked may compromise the seal and damage the mechanical lockout and valve. • At maintenance or repair of an actuator, it shall be disconnected as described in section B8. The pipe section must be free from pressure and completely drained at both sides of the valve before any maintenance begins. • Some valve types can be installed as end valves. Contact Stafsjö for specific requirements and further information. • The temperature of the exterior parts of the valve depends of the fluid temperature inside – any protective insulation is in the responsibility of the user. • When the SLV and SLF valve body are closed by bottom cover and/or when SLH and SLX purge ports are closed by plugs, flushing is recommended through the purge ports at service if it is not clean fluid.
 <p>Danger</p>	<ol style="list-style-type: none"> 1. The stuffing box packing together with the gland makes sure that no media reaches surrounding environment where the gate exit the valve body. When the stuffing box packing (braids) shall be changed, the gland bolts must be loosened, and the the pipe section shall be depressurised and empty. 2. A valve with an actuator shall be actuated only if: <ul style="list-style-type: none"> • The valve is installed between flanges or between a flange and a protective device. • The gate guards are installed on the beams, on automatic operated valves. 3. If you install the knife gate valve as an end valve in a pipeline, always install protective equipment to prevent people getting to close to the valve and being exposed to the media transported in the system when the valve opens. <p>People's life and health is at stake if this is not observed. Any other action is the responsibility of the user.</p>

C2 Manual and automatic actuation

A knife gate valve with handwheel closes clockwise as standard. Exceptions may occur based on customer requests.

A valve with automatic actuator is operated following the signals from the plant control system. Valves equipped with actuator supplied by Stafsjö are exactly adjusted to stop in the exact end positions. This adjustment shall not be changed as long as the valve operates correct.


Valves with infrequent operation:

Stafsjö recommends a full operation test (open and close) at least twice a year (six months frequency) at normal operating conditions. For severe services and/or specific application more frequent test intervals may be needed. It is at the user's responsibility to evaluate which interval is suitable for their application/ process.

C3 Maintenance

Inspect the valves on regular basis for any leakages. Seat and box packing are wear parts that have to be replaced regularly. The interval for both inspection and replacement depends on the application and operating data such as pressure, temperature, erosion, chemical, mechanical effect of the media on the materials in the knife gate valve and on how often the valve is operated.

If a leakage is detected in the stuffing box area, re-tighten the nuts on top of the gland according section B7. If the leakage does not stop or if any other leakage is detected, the valve needs to go through maintenance.

 Danger	Make sure to implement necessary safety precautions for the personal if any leakage is detected on an installed valve, see section C.1
--	--

A threaded stem is used on hand wheel, bevel gear and electric operated valves to open/close the valve. The stem is greased upon delivery – make sure to grease it on regular basis.

C4 Troubleshooting

Problem	Reason	Measure
Leakage from stuffing box packing	Gland bolting too loose* Worn-out box packing Incorrectly installed box packing Damaged gate	See relevant maintenance instructions issued by Stafsjö <i>Download: www.stafsjo.com</i>
Leakage at flange connection	Wrong length of bolts in flanges Loose flange bolting Valve not centred at flange connection Valve not parallel to flanges Gasket not centred Wrong gasket material	See this instruction, section B7 See Stafsjö's maintenance instructions and relevant data sheet <i>Download: www.stafsjo.com</i>
Leakage through valve bore	Worn-out seat/sealing profile Valve does not close 100% Damaged seat or gate	See relevant maintenance instructions issued by Stafsjö <i>Download: www.stafsjo.com</i> See instruction for actuator (if any)
Gate does not open/close completely	Fault in actuator Fault in limit switch setting Valve clogged Damaged seat/sealing profile or gate	See instruction for actuator/accessories See the relevant maintenance instructions issued by Stafsjö <i>Download: www.stafsjo.com</i>
Gate does not open/close in a smooth movement	Fault in actuator Valve clogged Damaged seat/sealing profile or gate Not enough air supply pressure Not enough air flow supply	See the relevant instruction for actuator See relevant maintenance instructions issued by Stafsjö <i>Download: www.stafsjo.com</i>
Too large force to open/close the gate (too high hand force as well)	Gland nuts tightened by too high torque Valve exposed to stress/tension Valve clogged or deformed Damaged seat/gate	See the relevant maintenance instructions issued by Stafsjö <i>Download: www.stafsjo.com</i>

* When tightening the gland bolts: See Table section B7

Stafsjö can offer maintenance of valves. Contact Stafsjö or your local representative for further information. Stafsjö does not accept any responsibility for the product if wear parts not tested and approved by Stafsjö are used on the valve. Stafsjö does not accept any responsibility for the product if maintenance instructions are not followed during maintenance.

Declaration of conformity with EU Directives

The manufacturer **Stafsjö Valves AB, SE-618 95 Stavsjö Sweden**, declares that knife gate valve types **D2G, HG, HL, HP, HX, JTV, MV, RKO, RKS, SLF, SLV, SLH, SLX, TV, WB and XV** are manufactured in accordance with the requirements of the following EU Directives and standards:

- **Pressure Equipment Directive (PED) 2014/68/EU**

The valves comply with this directive. The conformity rating procedure used, is according to Annex III, category I and II module A2. The valve is CE marked when it is applicable.

Notified body: **TÜV NORD Scandinavia AB, Reg.-No. 2529**

Certificate no: **TNSE-PED-23-226**

- **Machinery Directive (MD) 2006/42/EC**

Non-manually actuated valves fulfil the demands in this directive as a “partly completed machine”. This declaration is considered as a Declaration of Incorporation, observe the table below. 2006/42/EC (MD) does not apply if the valve is manually actuated. The specific technical documentation for partly completed machine according to Annex VII, Part B can be provided electronically upon request from responsible authorities. The following harmoniserad standard have been used: EN ISO 12100:2010” Safety of machinery – General principles for design – Risk assessment and risk reduction”

- **ATEX Directive 2014/34/EU**

For Group II, 3 G/D (zone 2 or 22). The directive is fulfilled only when the valve is labelled with EX-marking:

For 3G: **CE** **Ex** II $\frac{3}{3G}$ Ex h IIC T6...T5 $\frac{Gc}{Gc}$
 $-20\text{ °C} \leq T_a \leq +60\text{ °C}$

For 3D: **CE** **Ex** II 3/3D Ex h IIIC T68 °C...T100°C Dc/Dc
 $-20\text{ °C} \leq T_a \leq +60\text{ °C}$

The ATEX directive 2014/34/EU does not apply if the valve is operated manually. The conformity rating procedure used is according to EN13463-5:2011 “Non-electric equipment intended for use in potentially explosive atmospheres – Part 5: Protection by constructional safety “C”

Stavsjö, May 2024



Maria Persson, General Manager

To comply with the Directives above, the following applies:

1. The use of the valve must comply with the <valve destination> defined in the “Original Installation and Service Instruction (“is-VALVES”)” supplied with the valve and must follow all instructions in this manual. If this manual is not followed, the manufacturer may – in serious cases – be released from his product liability.
2. A separate declaration may be supplied for the actuator.
3. The valve shall not be put into operation until the facility owner has made the required risk analyses and declared compliance with the above Directives. Consideration must also be given to any separate actuator instructions.
4. Staffsjö Valves AB has made and documented the required risk analysis; the Staffsjö AB employee responsible for this documentation is Oskar Rüdow, see the manufacturer’s address.

Manufacturer Staffsjö Valves AB SE-618 95 Stavsjö, Sweden, declares that a STAFSJÖ knife gate valve complies Directives 2006/42/EC as follows:	
Requirements as per Annex I of the Directive 2006/42/EC	
1.1.1, h) Valve destination	See original installation and service instruction.
1.1.2, c) foreseeable misuse	See original installation and service instruction, section B1 and C1.
1.1.2, d) protecting measures personnel	Same as the pipe section into which the valve is installed. See original installation and service instruction, section B1.
1.1.2, e) accessories for maintenance	No special tools are necessary.
1.1.3 material in contact with the fluid	All valve material in contact with media are specified in the order acknowledgement and/or on the valve’s marking. The relevant risk analysis is the responsibility of the user.
1.1.5 handling	See original installation and service instruction.
1.2 and 6.2. control system	Is the responsibility of the user in combination with the instruction of the actuator.
1.3.2 withstand to stresses	For parts under pressure: See declaration of conformity to the PED 2014/68/EU For functional parts: Ensured at contractual use of the valve.
1.3.4 sharp edges or angles	Requirements fulfilled.
1.3.7/.8 risks related to moving parts	Requirements are fulfilled at contractual use of the valve, see original installation and service instruction. Observe the warnings. Delivered gate guards must be installed on the valve. No maintenance is allowed when the pipeline is pressurized, or the automatic controlled actuator is connected. If the valve is modified by the customer (new actuator) necessary protective devices shall be installed. Ask Staffsjö for support.
1.5.1 – 1.5.3 energy supply	Is the responsibility of the user in combination with the instruction of the actuator.
1.5.5 contact to surface with high/low temp.	See warning in the “Original installation and service instruction”.
1.5.7 -explosion	Ex -protection may be necessary. This shall be confirmed in Staffsjö’s order acknowledgement. Observe the valve’s marking and relevant instruction from Staffsjö.
1.5.13 emission of dangerous substances	Not applicable at not dangerous fluids. For dangerous fluids: pay attention when re-tightening the gland box. Personal safety equipment may be necessary.
1.6. maintenance	See original installation and service instruction.
1.7.3 marking	Knife gate valve: see original installation and service instruction. Actuator: see actuator instruction.
1.7.4 service instruction	See original installation and service instruction and actuator instruction.
Requirements from Annex II	Automatically manoeuvred valves fulfil the demands in this directive as “partly completed machine”. This declaration is considered as a declaration of Incorporation.
Requirements from Annex III	The knife gate valve is not a complete machine. No CE marking for conformity with the directive 2006/42/EG.
Requirements from Annexes IV, VIII to XI	Not applicable.